

Office chair (F94)

BS 5459 certified seating



Features

The F94 is an ergonomic office chair offering superb support and ergonomics for any office environment.

1. Optional headrests with height and angle adjustment (can be retro-fitted)
2. Upper back designed for great thoracic support
3. Height adjustable (5 settings) backrest.
4. Integrated lumbar supporting lower back. Removable height-adjustable Lumbar Panel
5. Robust soft-weave mesh upholstery for ventilation and pressure distributions
6. Single paddle level control to activate seat height and dynamic movement
7. Tension control
8. Synchronised mechanism at 2:1 ratio. Seat depth can be built in two position
9. Rounded waterfall seat front
10. Multifunctional arm rests with soft touch pads (Arms can be removed).
11. Aluminium five-star base as standard

Options

- 56 textile options /custom upholstery options available, including vinyl and leather for seat pads available on request
- Black aluminium base
- White frame
- Coat hanger
- Integrated legrest
- Mesh upholstery for seat
- Ergonomic (height & angle) or wider executive (height adjustable) headrests
- Footstool
- Extended warranty
- Fully assembled delivery

BS 5459 certified

Manufactured to BS 5459-2:2000+A2:2008 standards, the specification for performance requirements and tests for office furniture.

This standard requires office pedestal seating to be suitable for use by persons weighing up to 150kg, and for use up to 24 hours a day. The chair provides a single shift setting guaranteed for 10 years reducing to 3 years for 24 hour environments